

DIESEL TANK TROUBLE SPOTS



1. Direct contact between wood cribbing and the tank invites corrosion. **2.** Stick-on foam insulation traps moisture. **3.** Uncoated mild steel will corrode quickly. **4.** Placing a tank where bilge water sits accelerates corrosion.